

## ピクニック籠・パン籠



10-017  
晒バスケット(大)  
30x25x20x32cm



10-018  
晒バスケット(中)  
26x21x16x24cm



10-019  
晒バスケット(小)  
24x18x14x20cm



10-023  
両手付フリーバスケット  
35x25x18x31cm



10-025  
角長手付フリーBOX  
35X25X18X34cm



10-026  
晒ミニボックス  
25x16x13x20cm



10-027  
晒トーフ籠(大)  
27x21x16x25cm



10-028  
晒トーフ籠(小)  
24x18x14x20cm



10-024  
晒角深型  
19.5x25cm



10-036  
晒ミニボックス(小)  
22.5x14x19cm



10-048  
晒二段重弁当  
21x24x29.5cm



11-333-01  
パン角長(大)  
22x14.5x6cm




11-333-03  
パン角長(小)  
20x12.5x5cm



11-337  
パン虎入角長  
16.5x10.5x7cm



11-707-01  
パン長角(大)  
22.5x11.7x7.5cm



11-707-03  
パン長角(小)  
18.5x10.5x7cm



14-207  
麻の葉盛器  
32x21x5x16cm



10-005  
麻の葉六角フリーボックス  
φ27x32cm